


FX Basics
Introduction

STOMPBOX DESIGN WORKSHOP

Esteban Maestre


CCRMA - Stanford University
August 2015

FX Basics: Introduction






FX Basics: Introduction



FX Basics: Introduction


Stompboxes traditionally operated in the analog domain. Here we will work with signals in the digital domain, by means of Digital Signal Processing (**DSP**) techniques.




FX Basics: Introduction

SIGNAL | PERIODIC SIGNAL





Signal: function of time, representing a given magnitude



Periodic Signal: signal whose value profile repeats over time: $s(t+T) = s(t)$






Some examples of basic periodic signals:



FX Basics: Introduction

SINUSOIDAL SIGNAL




$\phi_0 = \text{phase (initial } \phi \text{ at time } t = 0)$

Angle ϕ at time t

$$s(t) = A \cdot \sin(\omega \cdot t + \phi_0) = A \cdot \sin(2 \cdot \pi \cdot f \cdot t + \phi_0)$$

$$A \cdot \cos(\omega \cdot t) = A \cdot \sin(\omega \cdot t + \pi/2)$$




FX Basics: Introduction

FOURIER ANALYSIS | FREQUENCY DOMAIN

Any function of time can be expressed as an **infinite sum of sinusoidal functions** of different frequencies, each function with a particular **amplitude** and **phase**.


Such function, previously expressed in the **Time Domain**, can therefore be expressed in the **Frequency Domain**.

The **Fourier Transform (FT)** is a **mathematical operator** that allows to go from Time Domain to Frequency Domain and vice-versa:



FX Basics: Introduction

FOURIER TRANSFORM OF IMPORTANT SIGNALS




FX Basics: Introduction

LINEARITY


The **Fourier Transform, $F[\cdot]$** , is a **linear operation**:

$$F[a \cdot x(t) + b \cdot y(t)] = a \cdot F[x(t)] + b \cdot F[y(t)]$$

TIME DOMAIN




+



FT

FREQUENCY DOMAIN



$$s(t) = x(t) + y(t)$$





FX Basics: Introduction

FOURIER TRANSFORM OF PERIODIC SIGNALS

TIME DOMAIN



FREQUENCY DOMAIN



HARMONIC SERIES:
Freq. of every **partial** (sinusoidal component) is a **multiple of fundamental frequency f_0**



This partial should correspond to the main oscillation

FX Basics: Introduction

EXAMPLE

Reconstruction of periodic signals using finite number of partials / harmonics.

- ORIGINAL SIGNAL
- RECONSTRUCTED




<http://www.youtube.com/watch?v=Lu2nnvYORec>
<http://www.youtube.com/watch?v=SpzNQ00BeRg>

FX Basics: Introduction



SHORT-TIME FOURIER TRANSFORM | SPECTROGRAM

Time sequence frequency domain representations




FX Basics: Introduction

EXAMPLE SPECTROGRAMS



CELLO PLAYING LOW NOTES
LOW FUNDAMENTAL FREQUENCY
NO VIBRATO



SOPRANO SINGING VOICE (in very old recording)
HIGH FUNDAMENTAL FREQUENCY
VIBRATO [software *SonicVisualizer*]




FX Basics: Introduction

FOURIER TRANSFORM OF SAMPLED SIGNALS


TIME DOMAIN



FREQUENCY DOMAIN



Repeated spectral images are called 'ALIASES'



f_s = sampling frequency

$f_s/2$ = Nyquist frequency
 BW = Bandwidth

NYQUIST-SHANNON THEOREM

Sampling frequency f_s must be at least twice the bandwidth BW

FX Basics: Introduction

DECIBELS | LOGARITHMIC SCALES

decibel (dB)

[1920s - **Bell Labs** defined it to measure losses in telephone cable]

Logarithmic unit indicating the ratio of a physical quantity (power or intensity) relative to a specified/implied reference level:

- Power units (e.g. Watts): $L_{dB} = 10 \cdot \log_{10}(P/P_{ref})$
- Amplitude units (e.g. Volts): $L_{dB} = 20 \cdot \log_{10}(V/V_{ref})$

→ Logarithmic scales (intensity and frequency) are more representative of **human perception**.

